#### Flow rate

• Up to 7.6 l/h Pressure

- Up to 17.3 bar
- Liquid ends
- Acrylic, stainless steel, PP, PVC, PVDF, designed for viscous products, designed for degassing products

LCD user interface with display of the calculated flow rate



Electromagnetic dosing pump

- User interface: easy reading and setup via an LCD screen
- Can be adapted to suit numerous applications and processes
- Quick installation and commissioning

#### **TYPICAL APPLICATIONS**

- Domestic hot water treatment: disinfection of systems (injection of disinfectant) and water conditioning (injection of scale inhibitor or corrosion inhibitor)
- Cooling water treatment: protection of cooling circuits (injection of corrosion inhibitor, non-oxidising biocide, anti-foaming agent), disinfection (injection of sodium hypochlorite - AutoPrime™ liquid ends)
- **Municipal water treatment:** proportional injection of chemical products, pH regulation (injection of acids/alkalis)
- Sludge treatment: sludge thickening and dewatering (injection of liquid polymers high viscosity liquid ends)
- Livestock farming: vaccination/medical treatment via drinking water (injection of medicines, vitamins or vaccines); reduction of health problems by acidification of the drinking water and (or) feedstuffs in mashing machines (injection of formic, fumaric or citric acid); disinfection of water (chlorine dosing), and cleaning and disinfection of tubing (dosing of hydrogen peroxide and chlorine dioxide)
- All industries: filling processes, continuous dosing processes, automated processes

#### FEATURES AND BENEFITS

- Easy to use: the (calculated) dosing rate is displayed directly in I/h or GPH
- Fully compatible with most chemicals used: liquid ends available in 5 different materials
- Can be adapted to suit the process: control can be manual, by pulse, by 4-20 mA signal, sequential via timer, batch injection, pulse division/multiplication, 24 VDC output, remote on/off
- Wide injection range: stroke frequency adjustable from 1 to 59 strokes/h and from 1 to 120 strokes/min; stroke length adjustable from 20% to 100% (50% to 100% recommended for AutoPrime<sup>™</sup> liquid ends)
- **Display of the pump status:** LED operating indicator and operating/ fault alarm
- High pumping capacity: double ball check valves
- Dosing of products requiring continuous automatic degassing: AutoPrime™ liquid end
- Dosing of high viscosity products: High Viscosity liquid end
- Monitoring of product transfer operations: single or dual level switch available as an option
- 2-year warranty

# **Technical** features



#### Materials/Construction of liquid ends and connections

- Liquid ends: acrylic, 316 stainless steel, PP, PVC, PVDF
- Liquid ends for viscous products
- AutoPrime™ liquid ends for degassing products requiring automatic degassing
- Priming bleed integrated in the liquid ends
- Balls: ceramic, PTFE or 316 stainless steel
- Connections available: metric or imperial low density polyethylene (LDPE), reinforced PVC, threaded (1/2" BSP)

#### **Electrical characteristics**

- Universal power supply: 95 V to 240 V
- Frequency: 50 Hz to 60 Hz
- Maximum current: 1.4 A

#### **Technical performance**

- 4 flow rate/pressure ranges:
- > Maximum flow rate: 7.6 l/h
- > Maximum pressure: 17.3 bar
- Accuracy of set flow rate:  $\pm\,2\%$
- Display of the calculated flow rate for easy adjustment and commissioning
- Selection of units: I/h or GPH
- Backlit screen for the AD9 series
- Suction lift: maximum 1.5 m
- $\bullet$  Maximum temperature of pumped fluids:  $\,+\,45~^\circ\text{C}$
- Maximum ambient temperature: + 45 °C
- Protective cover

#### **Performance**

- Protection: IP65 (external control connectors IP68)
- Linear stroke frequency adjustment: from 1 to 59 strokes/h and from 1 to 120 strokes/min
- Linear stroke length adjustment: from 20% to 100% recommended. With AutoPrime™ liquid end: from 50% to 100% recommended
- On/off switch
- Pushbutton: Increase/Decrease speed
- **Pushbutton:** Internal mode/External mode with 2-colour (yellow/green) LED operating indicator
- LED operating indicator: on, fault and alarm indication

	ΜΔΧ			STROKE CAPACITY (ml)		FREQUENCY (spm)		MIN. Stroke Length	MIN. Flow Rate	CONNECTIONS					
MODEL	FLOW RATE	MAX. Pressure	DIAPHRAGM SIZE							Plast	ic liquid e	ends	S.S. liquid	High viscosity liquid ends	
	(l/h)	(bar)	(inch <sup>2</sup> )	min.	max.	min.	max.	(%)	(ml/h)	LDPE inch	LDPE metric	Reinforced PVC	ends	inch	
With FastPrime™ liquid end															
AD81*	0.8	17.3	0.2	0.02	0.11	0.02	120	20	160	0.250"OD	3x6mm	6x12 mm	1/4" NPTm	0.500"OD	
AD84*	1.9	17.3	0.4	0.05	0.26	0.02	120	20	380	0.250"OD	3x6mm	6x12 mm	1/4" NPTm	0.500"OD	
AD85*	3.8	7.6	0.8	0.11	0.53	0.02	120	20	760	0.375"OD	6x8mm	6x12 mm	1/4" NPTm	0.500"OD	
AD86*	7.6	3.4	1.6	0.21	1.06	0.02	120	20	1 5 2 0	0.375"OD	6x8mm	6x12mm	1/4" NPTm	0.500"OD	
AD91*	0.8	17.3	0.2	0.02	0.11	0.02	120	20	160	0.250"0D	3x6mm	6x12 mm	1/4" NPTm	0.500"OD	
AD94*	1.9	17.3	0.4	0.05	0.26	0.02	120	20	380	0.250"0D	3x6mm	6x12 mm	1/4" NPTm	0.500"OD	
AD95*	3.8	7.6	0.8	0.11	0.53	0.02	120	20	760	0.375"OD	6x8mm	6x12 mm	1/4" NPTm	0.500"OD	
AD96*	7.6	4.3	1.6	0.21	1.06	0.02	120	20	1520	0.375"OD	6x8mm	6x12 mm	1/4" NPTm	0.500"OD	
With AutoF	Prime™ I	liquid end (f	or degassing	produ	cts)										
AD81*	0.6	10.3	0.2	0.02	0.08	0.02	120	50	120	0.250"0D	3x6mm	6x12 mm	1/4" NPTm		
AD84*	1.2	10.3	0.4	0.03	0.17	0.02	120	50	240	0.250"0D	3x6mm	6x12 mm	1/4" NPTm		
AD85*	3	7.6	0.8	0.08	0.42	0.02	120	50	600	0.375"OD	6x8mm	6x12 mm	1/4" NPTm		
AD86*	6.8	3.4	1.6	0.19	0.94	0.02	120	50	1360	0.375"OD	6x8mm	6x12mm	1/4" NPTm	NOT	
AD91*	0.6	10.3	0.2	0.02	0.08	0.02	120	50	120	0.250"0D	3x6mm	6x12 mm	1/4" NPTm	APPLICABLE	
AD94*	1.2	10.3	0.4	0.03	0.17	0.02	120	50	240	0.250"0D	3x6mm	6x12 mm	1/4" NPTm		
AD95*	3	7.6	0.8	0.08	0.42	0.02	120	50	600	0.375"OD	6x8mm	6x12 mm	1/4" NPTm		
AD96*	6.8	3.4	1.6	0.19	0.94	0.02	120	50	1360	0.375"0D	6x8mm	6x12mm	1/4" NPTm		

When ordering, please specify the voltage code by using one of the following numbers: 3 = 95-240 V, DIN plug / 5 = 95-240 V, UK plug / 8 = 95-240 V, without plug



#### Control modes

- Manual control by linear adjustment of the stroke frequency and stroke length
- External pulse control by volt-free contact with integrated control pulse division/multiplication (from 1 to 999). The stroke frequency is then set by external pulses, for example from a water meter
- Direct external proportional control by 4-20 mA analogue signal (direct or indirect response).
- The amount of product injected is proportional to the intensity of the input signal in mA
- Power supply output (24 VDC) for connection of accessories such as a flow monitor
- Remote on/off
- Possibility of connecting a level switch (optional accessory) to monitor the product transfer operation
- Possibility of connecting a Digi-Pulse<sup>TM</sup> flow monitor to monitor the flow rate automatically and trigger an alarm if there is a fault

#### AD9 series only

The AD9 series can supply the following information as an output via a 6-pin connector:

- Pulses: the pump will supply a 100 ms pulse each stroke
- 4-20 mA analogue signal
- Remote alarm transfer
- · Remote control of the switch between internal and external mode
- Closing of the alarm contact

#### AD9 series advanced configuration menu

- 7-day event timer: pre-programmed triggering of injection at the correct time with no intervention of any external device
- Batch accumulation dosing: if the pulse multiplication setting is selected, this option is used to accumulate the dosing of the batches. A batch is dosed each time the pump receives an external pulse. If the pump receives new pulses before a batch is complete, this setting makes it possible to take account of these pulses and deliver the dosed amount of product. If this option is inactive, the pulses are ignored
- Pulse width: programming of the pulse width (from 4 ms to 60 ms, in 4 ms increments) so that it is exactly right for the process
- Percent-of-time operation: programming of injection cycles (for example, the pump will inject for 2 minutes and will then be stopped for 8 minutes)
- Pump calibration: quick, simple calibration of the pump to adapt it to the actual conditions of use
- Remote alarm transfer
- Alarm: stops the pump according to the alarm mode selected
- Closing of the alarm contact: remote stopping of the pump by an external contact signal, without having to switch off the electricity supply to the pump
- Locking: protection of the pump's settings, avoiding incorrect operation. The pump can be locked using a 4-digit code
- · Remote control of the switch between internal and external mode
- Return to default factory settings

#### Accessories

Excel<sup>TM</sup> AD pumps are delivered ready to use. For standard liquid ends, apart from the stainless steel version, the following accessories are supplied with the pump: an injection nozzle, a foot valve, a ceramic weight, connection and bleed tubing, and the external control cable(s) (depending on the model).

A 4-function valve is an ideal addition for your installation. The **anti-siphon** function enables downstream dosing or dosing in a low pressure line; the **back pressure valve** function maintains a counter-pressure of 1.4 bar on the dosing pump to prevent excess flow due to lack of discharge line pressure; the **priming** function enables the pump to be primed even if it connected to a pressurised line; the **line depressurisation** function makes it easier to carry out maintenance operations by depressurising the discharge line without having to loosen or disconnect the tubing.

Milton Roy Europe proposes a wide range of accessories to complete the

installation of your

pump.

Spare parts

Milton Roy Europe advises you on the essential wear parts to be kept on hand in order to optimize the performance of your equipment.



#### **Dosing stations**

A turnkey solution Compact and fully-featured, DOSAPACK<sup>®</sup> stations are ideal for the preparation, storage and injection of reagent solutions.





## Coding | Standard & options

### PLASTIC LIQUID ENDS

Exce	I™ AD															
AD	Electr	omagn	etic dosi	ina pump B	xcel <sup>™</sup> AD											
	Contr	ol		51-1-1-												
	8	Series	AD8 - Pu	lse control /	4-20 mA	/ Dual ma	anual cont	rol / Flow r	rate displa	y (calculated	)					
	9	Series	AD9 - Pro	ogrammable	e / Pulse co	ontrol / 4-	20 mA / [	Dual manua	al control /	Flow rate d	, isplay (calcu	lated)				
		Outpu	it (max. F	low rate /	Pressure)	)										
			F	astPrime™	<sup>4</sup> liquid end				AutoPrim	e™ liquid (	end					
				l/h	ba	ar		l/h		bar		AutoPrime	hiunil ™	end recor	nmended	
		1		0.8	17	.3		0	.6	1	0.3	for product	ts which	require a	itomatic	
		4		1.9	17	.3		1	.2	1	0.3	and contin	niis deus	esina	tomatio	
		5		3.8	7.	.6			3	7	.6		ouo uogu	oomg		
		6		7.6	3.	.4		6	.8		3.4	_				
		-	Power supply													
			3	95-240 V	, DIN plug											
			0	95-240 V	, UK piug without p	lua										
			0	90-240 V	, without plug		_	_	_	_	_	_	_	_		
					Liquiu ei	iu mater	lai									
					/	ADx1	ADx4	ADx5	ADx6	Head	Fittings	Cartridges	Seats	Seals	Balls	
					FastPrim	e™ liau	id end									
					812	×				PVDF	PVDF	PVDF	PTFE	Aflas®	Ceramic	
					813	×				PDVF	PVDF	PVDF	PTFE	PTFE	Ceramic	
					818	×				PVC	PVC	PVDF	PTFE	Aflas®	Ceramic	
					910	×				Acrylic	PVC	PVDF	PTFE	Aflas®	Ceramic	
					915	×				PP	PP	PVDF	PTFE	PTFE	Ceramic	
					919	×				Acrylic	PVDF	PVDF	PTFE	Aflas®	PTFE	
					822		×			PVDF	PVDF	PVDF	Aflas®	Aflas®	Ceramic	
					823		×			PVDF	PVDF	PVDF	PTFE	PTFE	Ceramic	
					828		×			PVC	PVC	PVDF	Aflas®	Aflas®	Ceramic	
					920		×			Acrylic	PVC	PVDF	Aflas®	Aflas®	Ceramic	
					925		×			PP	PP	PVDF	PTFE	PTFE	Ceramic	
					929		×			Acrylic	PVDF	PVDF	Aflas®	Aflas®	PIFE	
					832			X		PVDF	PVDF	PVDF	ATIAS®	ATIAS	Ceramic	
					033			×		PVDF	PVDF	PVDF	Afloo®	Afloo®	Coromio	
					030			×		Acrylic	PVC		Allas <sup>®</sup>	Allas <sup>®</sup>	Coramic	
					035			~		PP	PP	PVDF	PTEE	PTEE	Ceramic	
					939			^ 		Acrylic	PVDF	PVDF	Aflas®	Aflas®	PTFF	
					842			~	×	PVDF	PVDF	PVDF	Aflas®	Aflas®	Ceramic	
					843				×	PVDF	PVDF	PVDF	PTFF	PTFF	Ceramic	
					848				×	PVC	PVC	PVDF	Aflas®	Aflas®	Ceramic	
					940				×	Acrylic	PVC	PVDF	Aflas®	Aflas®	Ceramic	
					945				×	PP	PP	PVDF	PTFE	PTFE	Ceramic	
					949				×	Acrylic	PVDF	PVDF	Aflas®	Aflas®	PTFE	
					AutoPrin	ne™ liqu	uid end fo	or degassi	ing produ	cts						
					910	×				Acrylic	PVC	PVDF	PTFE	Aflas®	Ceramic	
					920		×			Acrylic	PVC	PVDF	Aflas®	Aflas®	Ceramic	
					930			×		Acrylic	PVC	PVDF	Aflas®	Aflas®	Ceramic	
					940				×	Acrylic	PVC	PVDF	Aflas®	Aflas®	Ceramic	
						Head /	Valve									
						N	For Fast	Prime™ lic	quid end or	nly - Standa	rd FastPrime	e™ liquid end				
						S	For Fasth	rime M lic	quid end oi	nly - FastPri	me i Miliquid	end + 4-funct	ion valve (a	anti-siphon	ing, back	
						٨	pressure	, priming, ( PrimoTM lie	depressuri auid and a	Zation) nhu Standa	rd AutoDrim	o TM liquid and				
						A	For Auto	PrimoTM lie	uid end o	niy - Stanua niv - AutoPri	moTM liquid	ond i A func	tion value /	anti cinhor	ing back	
						Н		nrimina (	donroccuri	riiy - Autorii zation)	IIIe ···· IIquiu		lion vaive (	anti-sipnoi	iiiy, Dauk	
							Connect	ions	ucpressuri.	2011011)						
							Connoo	For FastP	Prime™ lio	wid end only	/ - Pine thre	ad (1/2" BSP).				
							0	Non avail	able on ac	rvlic liquid e	nds	uu (172 001).				
							2	For FastP	rime™ ar	nd AutoPrime	e™ liquid er	nds only - Inch	tubing cor	nnections		
							3	For FastP	rime™ ar	nd AutoPrime	e™ liquid er	nds only - Metr	ric tubing o	connections		
							Л	For FastP	rime™ lic	uid end N c	ode and Aut	oPrime™ liqui	d end A co	ode only - F	leinforced	
							4	PVC tubir	ng (6x12 n	nm). Non ava	ailable on liq	uid end with 4	-functions	valve (B or	S code)	
	9	4	3	-	828	Ν	3									
		1					1									



## STAINLESS STEEL LIQUID ENDS

Exce	Excel™ AD														
AD	Electromagnetic dosing pump Excel <sup>™</sup> AD														
	Contro	Control													
	8	Series	AD8 - Puls	se control /	4-20 mA	/ Dual ma	nual contr	ol / Flow r	ate display	(calculated	)				
	9	Series	AD9 - Programmable / Pulse control / 4-20 mA / Dual manual control / Flow rate display (calculated)												
		Output	utput (max. Flow rate / Pressure)												
			Fa	lstPrime™	<sup>1</sup> liquid er	nd									
		/	l/h bar												
		1	0	.8	.3										
		4	1	.9	17	.3									
		5	3	.8	7.	6									
		6	7	.6	3.	4									
			Power supply												
			3	95-240 V	O V, DIN plug										
			5	95-240 V	) V, UK plug										
			8	95-240 V	without plug										
				-											
					Liquid er	id mater	ial								
					/	ADx1	ADx4	ADx5	ADx6	Head	Fittings	Cartridges	Seats	Seals	Balls
					Stainless	steel lic	uid end								
					917	×				316	316	-	316	PTFE	316
					927		×			316	316	-	316	PTFE	316
					937			×		316	316	-	316	PTFE	316
					947				×	316	316	-	316	PTFE	316
AD	9	4	3	-	927										

### HIGH VISCOSITY LIQUID ENDS

Exce	el™ AD														
AD	Electr	omagn	etic dos	sing pump E	xcel™ AD	)									
	Contr	ol													
	8	Series	AD8 - P	ulse control /	4-20 mA	/ Dual ma	anual contr	ol / Flow r	ate display	y (calculated	1)				
	9	Series	AD9 - P	rogrammable	/ Pulse co	ontrol / 4-	20 mA / D	ual manua	al control /	Flow rate d	isplay (calcul	ated)			
		Outpu	t (max.	Flow rate /	Pressure	)									
		FastPrime™ liquid end													
				l/h	b	ar									
		4		1.9	17	7.3									
		5		3.8	7	.6									
		<b>6</b> 7.6 3.4													
		Power supply													
		3 95-240 V, DIN plug													
			8	95-240 V	without n	lua									
			0	- 30-240 V	without p	iug									
					Liauid e	nd mater	ial								
					,		4.0.4	ADUE	40.0	Head	E Himan	Orabidada	0	Quala	Delle
					/	ADXI	ADX4	ADX5	ADX6	Head	Fittings	Cartridges	Seats	Seals	Balls
					High vise	cosity liq	uid ends								
					624		×			PP	PP	-	PTFE	PTFE	316
					626		×			Acrylic	PP	-	Viton®	Aflas®	316
					634			×		PP	PP	-	PTFE	PTFE	316
					636			×		Acrylic	PP	-	Viton®	Aflas®	316
					644				×	PP	PP	-	PTFE	PTFE	316
					646	llead ()	lelue.		×	Acrylic	PP	-	Viton®	Aflas®	316
							High vice	ocity liquid	Lond						
4.0					004	V									
AD	9	4	3	-	624	V									



## **Dimensions** and packing

